

RV-10 Axle Extension Replacement

Kit Contains:

(1 pr.) Axle extensions (2) AN5-6A bolts (2) MS24693C298
(2) MS24665-292 cotter pins (2) MS24665-362 cotter pins

Drill existing holes on the axle nuts out to 5/16" and deburr. Then assemble the AN5 bolt/washer to the extension and torque (100 Inch-Pounds). Then, use a #40 drill through the guide hole and drill out the hole and the bolt to #40. Pin them together with the small cotter pins, install the axle nuts and pin with the large pins. Then secure the fairing with the 1/4" stainless machine screw.

